

Product Service Bulletin

PSB#050885

Replace Present Dome Slider with Trapezoidal
Dome Slider

May 5, 1985

INSTALLATION AND PACKING INSTRUCTIONS:

1. Be sure the slider is installed with the long edge to the rear of the canopy.
 2. Attach a rubber band to either of the center "B" line attachment tapes and stow 6-8 inches of the slider in it. A slider works best if it is tight up against the slider stops at line stretch.
 3. Fold the canopy nose over, on top of the "A" line connection point, and then make another equal fold in the same direction, before "S" folding the rest of the canopy. This will protect the nose from the slipstream until the slider has a chance to inflate.
- Care should still be taken while the canopy is new. Do not exceed the 10 second freefall limit especially with heavy loads. If you have any questions, do not hesitate to call.

William Booth

William Booth
President