



**VECTOR 3 MAIN PACKING TIPS**

**Problem:**

If the inner risers tend to come out or crease out of place then try these tips.

**Solution:**

Leave about 20" from the last stow to the risers. (this depends on the length of your main risers)  
Make sure you set the risers through their proper channel.



After both risers are routed, push them under the rig as showed.



If you place the bag how it is supposed to fit in the main container, and then you push it down, it will give a better shape to the container, rather than placing the bag straight down and then rotating it.



Check your main closing loop; make sure that is in good shape.

Use your closing device (Pack boy or pull up cord) and close flap number 1, please notice how the bridle is placed under the flap.



When closing flap number 2 push the inner riser covers down to give a better memory and better look to your rig, repeat the same steps on flap number 3.



Now that all the flaps are closed, place the pin in the closing loop and make sure that the grommets are off set.



Close the pin cover flap, and route the bridle to the center of the BOC and fold the pilot chute.