

UNINSURED **UNITED PARACHUTE TECHNOLOGIES, LLC.**

VECTOR



SKYHOOK

SIGMA

Line Stow Procedure for the Sigma 2 ALD (Anti Line Dump) Bag

Video demonstrating this procedure is available at
<https://www.youtube.com/watch?v=qgA8JhZc4w>



Use canopy flaking and packing techniques as described in the Sigma Tandem Manual Pages 96-104.

The ALD Bag has two stamps to assist in orienting the bag for packing and to clarify the order of closing the flaps. Red circle added for emphasis. Flap one will lay flat under the canopy while the canopy is cocooned on the floor and will be closed first. Flap two is closed once the stows are completed on Flap 1.

Stamp Locations on ALD Bag





Maintaining tension on the lines and control of the parachute, insert one side of the parachute into the main d-bag. Pull the main d-bag over the parachute to assist in placing the parachute. Fill the corners of the main d-bag completely.



Top View



Route the center rubber bands through the corresponding center grommet on Flap 1 and stow line bight. Length of bight should be 3". Double wrap all rubber bands.



Continue stowing locking stows, alternating sides in sequence. Double wrap all rubber bands.



Continue stowing line bights to alternate sides of Flap 1. Double wrap all stows. Line bights should be 3”.



Close Flap 2 over Flap 1 line stows. Stow center locking stow. Double wrap the rubber band. Line bight should be 3”.



Split lines into left and right riser groups. Stow each line group in the corresponding locking stow for each side. Leave about 2 feet of line between the last stows and the risers.

Continue with standard Sigma main packing procedures. Refer to the Sigma Tandem Manual pages 106-113 for bag placement in the main pack tray, closing the main pack tray, and setting and stowing the drogue.