



Removable Belly Band Installation

1.



Place buckle side of belly band on left side of the container at the lower junction aligned with the stabilizer.

2.



Wrap bottom attachment loop around the backside of the main life web.

3.



Pass friction adapter through lower attachment loop.

4.



*Detail of friction adapter and lower loop properly seated.

5.



Pass upper loop around the back side of the main lift web.

6.



*Detail of the back side of the main lift web and both loops of the belly band.

7.



Pass upper loop around buckle, left side is now attached.

8.



*Detail of completed left side from the backside of the main lift web.

WARNING: If attaching on a container with a reserve D-handle, verify that the belly band loops do not pass through the reserve D-handle

9.



Place webbing side of belly band on right side of the container at the lower junction aligned with the stabilizer.

10.



Wrap bottom attachment loop around the backside of the main life web.

11.

Pass belly band strap through lower attachment loop.

12.

Pass upper loop around strap, right side is now attached.

13.

*Detail of completed left side from the backside of the main lift web.

14.

Pass strap through belly band pad.

15.

The Belly Band is now ready for jumping.